



1999 Maintenance Schedule

	Miles Kilometers	5 8	10 16	15 24	20 32	25 40	30 48	35 56	40 64	45 72	50 80	55 88	60 96	65 104	70 112	75 120	80 128	85 136	90 144	95 152	100 160	105 168
TDI																						
Engine Oil – change		•	•		•		•		•		•		•		•		•		•		•	
Engine Filter – change		•	•		•		•		•		•		•		•		•		•		•	
Water Sep. – drain		•	•		•		•		•		•		•		•		•		•		•	
Timing Belt – check condition		•	•		•		•		•		•		•		•		•		•		•	
Fuel Filter – replace					•				•				•				•				•	
Timing Belt – replace**													•									
Timing Belt Tensioner – replace***													•									
1.8T																						
Engine Oil – change		•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
Engine Filter – change		•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
V-Belt – replace																	•					
Spark Plugs – replace									•								•					
Timing Belt – check condition									•								•					
Timing Belt – replace																						•
Timing Belt Tensioner – replace																						•
2.0																						
Engine Oil – change		•	•		•		•		•		•		•		•		•		•		•	
Engine Filter – change		•	•		•		•		•		•		•		•		•		•		•	
Spark Plugs – replace (all but New Beetle)					•				•				•				•				•	
Spark Plugs – replace (NB)									•								•					
Timing Belt – check condition									•								•					
VR6																						
Engine Oil – change		•	•		•		•		•		•		•		•		•		•		•	
Engine Filter – change		•	•		•		•		•		•		•		•		•		•		•	
Spark Plugs – replace									•								•					
V6																						
Engine Oil – change		•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
Engine Filter – change		•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
Spark Plugs – replace									•								•					
Timing Belt – check condition									•								•					
Timing Belt – replace																						•
Timing Belt Tensioner – replace																						•
All Cars																						
W/W Fluid – check level			•		•		•		•		•		•		•		•		•		•	
Auto-Shift Lock – check			•		•		•		•		•		•		•		•		•		•	
Brake System – check			•		•		•		•		•		•		•		•		•		•	
Wheels – rotate front to rear			•		•		•		•		•		•		•		•		•		•	
Battery – check electrolyte level					•				•				•				•				•	
Dust Pollen Filter – replace					•				•				•				•				•	
Manual Trans. – check for leaks					•				•				•				•				•	
Automatic Trans. – check for leaks					•				•				•				•				•	
Tires/Spare – check condition					•				•				•				•				•	
Drive Shafts – check boots					•				•				•				•				•	
OBD – check DTC memory					•				•				•				•				•	
Door Check Straps – lubricate					•				•				•				•				•	
During Road Test					•				•				•				•				•	
After Road Test					•				•				•				•				•	
Air Cleaner* – replace filter									•								•					
Cooling System – check level					•				•				•				•				•	
V-Belt – check tension/condition									•								•					
Ribbed Belt – check condition									•								•					
Front Axle – check									•								•					
Check ATF and diff. level									•								•					
Headlights – adjust					•				•				•				•				•	

*Every 40,000 miles and 4 years; except Passat and EuroVan, every 2 years

**Recommended

***Recommended; replace once only

Brake Fluid – change every 2 years regardless of mileage

Air Bag System – check for function and damage after 4 years, 8 years and every 2 years thereafter